



DIY for the installation of the Steering Wheel Audio Controls

Order the controls from CustomSorento.com or you're your Kia Dealer part no 967303E310 you will need an interface unit for your stereo and cable. I got mine from <http://www.caraudioredirect.co.uk/>

Once you have the bits the install is really straight forward, but as you are dealing with the airbag follows them.

1. Disconnect the battery then go and do something else for 5 mins while the capacitors discharge. Don't even think that removing the fuse is sufficient.
Disconnect the battery then go and do something else for 5 mins



2. Using a T40 driver remove the 2 screws behind the round caps, the airbag is now removable.



3. Allow the unit to come forward, Kiamech advised me to remove the yellow plug, but I decided to leave it on.



4. Disconnect the white plug and the lead which goes between the airbag and this connector, you will reconnect it to the new harness.



5. Remove the two decorative side pieces (simply pull) I then put the controls to them and run a strip of hot melt glue along the joint, there are 2 screw holes in the controls, but nothing to fix them to, hence the glue gun approach. Set the decorative strips back in place and hold the controls to the wheel casing, apply more glue around the joints



6. Replace the airbag and tighten the bolts.



Thanks go to Kiamech for the advice on how to do this project