



## Installing the IMMO Chip inside your Flip out Key By LXEDITION

### **Tools:**

Hacksaw or rotary tool with a cut off wheel  
Hair dryer or Heat gun  
3M two way tape  
Small Philips screw driver  
Two pliers

### **Duration:**

20 to 30 minutes

### **The before picture:**



1. Take your OEM key and cut the sides and the back of the key until you see the silver portion of the key.
2. Now take your heat gun or hair dryer and heat up one side making sure you heat up the sides of the key as well. Make sure you have one of the pliers is holding the front of the key if not your going to burn your fingers.
3. Next grab the plastic with the other set of pliers and pry off the plastic off the key.
4. Do the same to the opposite side and you should be left with this:



*Yeah, yeah, I need new pliers this is what a week out in a snow bank will do...*

5. Next take your two pliers on the both sides of the key (the metal parts) and twist the ends until the plastic center holding the chip pops out.
6. From here I just found it easier to open up the flip key with unscrewing the two black screws on the back of the flip key. There is a spring that will go flying if your not careful open it up. Below is where I placed the chip with 3M tape.



7. Putting the flip key back together is easy take the back side of the key line the spring up twist the spring one full turn and snap the key back together and tighten the screws. You'll be left with this :

